

Controltac Positionable Vinyl Graphics

Low Tack Removable Vinyl Installation Instructions

Installation Steps:

1. **First and foremost, be sure the surface to which the vinyl will be applied is clean, dust-free and free of any oils or grease.** Also make sure that the surface is dry before application! The vinyl, unlike other products, **must be applied dry without water.**
2. Slowly and gently remove the vinyl from the backing sheet in order to avoid wrinkles and creases. Pull from the corners then straight down the sheet. Do not apply extreme pressure on the adhesive on the back, as it will depress the specially designed adhesive.
3. Start from the top during application and drape the film over the surface to which it is being installed. Slowly move the hands down the sheet until you reach midpoint. At that point, move the hands out to the side of the sheet and press. Continue that operation down the rest of the sheet until the film is completely installed.
4. Keep in mind that the film is removable. Should wrinkles occur, pull back the film, smooth out the wrinkles and reapply. Should air bubbles occur, do the same, pull back the film and smooth out the bubbles by forcing them to the edges and allowing them to escape. **Best application occurs when you smooth out the wrinkles and air bubbles during the initial smoothing phase. You will maximize the application bond if you don't have to pull back the film again to re-smooth.**
5. Please keep in mind that you do not want to fully compress the adhesive of the back to the surface before the film is in its position and has all the wrinkles and bubbles out. Once you are at this step, you can fully compress the film to the surface in order to create the strongest adhesive bond.
6. As with any product, the film should be fully tested first on your part for optimum reliability and performance.