

# Panoramic™ Frame

Component - Pano\_Wall\_20\_A


Frame Installation

Parts -	total # of pieces	Pano_L-Frame	Pano_I-Frame	Pano_F-Frame Horizontals
Pano_L-Frame	4			
Pano_I-Frame	6			
Pano_F-Frame - Top	13			
Pano_F-Frame - Bottom	13			
W:235.75" D:17.3" H:94.5"				



Step 1 - Arrange bottom Pano\_F horizontal sections in place according to frame detail. Corner connectors will already be in place and sections will be labeled with a single letter at each end.





**Note: Frame connection points are labeled with letters. Graphic installation points are identified with numbers.**



Step 2 - Place assembled vertical posts down onto corner connector on horizontal section. Do one wall or section at a time. Tighten D screws on vertical posts.









Step 3 - Top horizontal posts will have the same labels as the bottom horizontals with corner connectors attached. Slide top extrusion connectors down onto tops of vertical posts. Tighten D screws on vertical posts.



*Helpful hint - Assemble one wall section at a time, then connect them.*  
*Example - connect A through D completely, then attach D/E, then the E through H section and so on.*

**Dismantle - Loosen D screws on vertical posts only to disassemble.**  
**Keep corner connectors attached to horizontals.**

**Note: Frame connection points are labeled with letters. Graphic installation points are identified with numbers.**







Step 1 - Identify start point on top of frame (fig. 1A, label-1) and graphic top left corner with start tab (fig. 1B, shown in blue).

Step 2 - Insert 1 Top corner of graphic and welt into top groove of L vertical post at point 1. Align welt on left with vertical groove, insert a few inches. See fig. 2

Step 3 - Align corner 2 of graphic with corner 2 on frame. Continue aligning corners around frame to final stop point.

**Corners must be done first to assure proper fit.**



Step 4 - Work in top welt between corners from center out to corners making sure graphic is evenly distributed.

Step 5 - For frames with multiple graphics, align next graphic with first. Follow steps 1-5 before doing sides and bottom.

Step 6 - Insert welt in vertical grooves between top and bottom corners. Work from middle out making sure graphic is evenly distributed. Take care to align continuous images.

Step 7 - Follow steps 1-5 for bottom of graphic.

**Be sure to push graphic into the groove, not slide.**